



The SafePro Automatic Roof Hatch Opener requires very little maintenance. Follow the schedule below to ensure problem free operation of your new A.R.H.O.

MONTHLY

1. Do a physical inspection on the entire ARHO system. Make sure all parts are moving freely. Make sure the latch release properly and does not constrain the opening of the hatch. Look for any loose wires that may be snagged while operating the hatch, or entering/exiting the hatch.
2. If you have a solar powered unit, check the solar panel to make sure the glass is not broken, and that it is clean of dirt and debris. This will ensure maximum charging for your battery.

SEMI-ANNUALLY

1. Check the charging status of your battery by pressing the status indicator button located on the front of the battery. If you notice that it is only charging to 75% or less, your battery is not operating at maximum capacity and needs replacement soon. A replacement battery is available from SafePro.
2. Check/Grease the rocker bracket and latch with a spray lithium grease, or silicone based spray. This will ensure smooth opening/closing of the hatch.
3. Make sure the Turnbuckle lock nut is securely against the Turnbuckle Rod. If the locknut moves, the Turnbuckle can re-adjust itself and cause the latch to not release. This can cause the hatch to bind causing damage to the ARHO system, or the roof hatch.
4. *If you have our Roof Hatch Safety Rail installed on your roof hatch, you will need to grease the hinges on this as well.*